

PowerAttendant Standard Edition Linux Version Upgrade Instructions

This document explains how to upgrade PowerAttendant Standard Edition for Linux (hereinafter referred to as PAS) from an older version to Ver.2.3.0.

If you are installing Ver.2.3.0 for the first time, please refer to the instruction manual and install it.



- PAS Ver.2.3.0 uses the ".NET 10.0" provided by Microsoft. Before installing this software, be sure to install ".NET10.0". For instructions on how to install ".NET10.0", please refer to the manual section "2 Installing the software"
- Regarding ".NET 6.0," which was used up to PAS Ver.1.1.1, it is not a problem to leave it installed.
- Regarding ".NET 8.0," which was used up to PAS Ver.2.2.0, it is not a problem to leave it installed. •



- When upgrading, be sure to uninstall the old version first, then install the Ver. 2.3.0 Please stall it. Do not perform overwrite installations.
- * If you uninstall, the configuration information will be deleted. Please make sure to note the configuration information before uninstalling, and after installing Ver. 2.3.0, please reconfigure the settings.

1. Record and Manage Configuration Information

For Ver.2.2.0 and later

Instruction manual "18. Importing and exporting configuration files" to export the configuration files.

For Ver.2.1.2 or earlier

After upgrading, make sure to manage your current settings by noting down your current settings so you don't forget them.

※ Instruction manual "18. Importing and exporting configuration files" for export before Ver.2.1.2 cannot be imported using Ver. 2.3.0.

2. Uninstalling Older Versions

The procedure varies depending on the type of OS you use.

Please Follow the steps in the instruction manual under "20. Uninstall software" to uninstall it.

3. Installing Ver.2.3.0

The procedure varies depending on the type of OS you use.

Please Follow the steps in the instruction manual under "2. Install the software" to install it.

4. Log in

Starting from version 2.2.0, the specification has been changed so that login is required to display the PAS screen.

After upgrading, when you launch PAS, a login screen will appear, so please enter your login ID and password to log in.



Login


Login Id Admin

Password

Login

5. Check Version Information

On the PAS screen, go to "Help" - "Version Info", and confirm that the version is Ver. 2.3.0.



6. Revert to the original settings

For Ver.2.2.0 and later

The configuration file exported using "1. Record and Manage Configuration Information" is imported according to the user manual "18. Importing and Exporting Configuration Files".

For Ver.2.1.2 or earlier

In "1. Record and Manage Configuration Information," please restore the settings you were managing to your original location.

This concludes the PAS Ver. The upgrade process to 2.3.0 is now complete.